




80-100




80-100



x2




x4



x4


BO-719

01.



Tirar del cajón hacia el frente y ligeramente hacia arriba para extraerlo
In order to extract the drawer, pull it forward and softly upwards.
Sortir le tiroir en le soulevant légèrement vers le haut pour l'extraire du meuble.
Die Schublade nach vorne und leicht nach oben ziehen, um Sie zu entfernen.
Per tirare fuori il cassetto alzi il fronte e leggermente verso di su.



02.






03.



cms.



04.



x2





x4




x4


BO-719




05.





06.






07.



08.




09.





WAVE Compact

Royo®




NON INCLUS / NOT INCLUDED




x2



x4



x4



x1



x1





x4













BO-850

BO-630



01.



02.



03.






x2

x4

x4




BO-850




04.



x4







x4
04.4



05.





BO-630





06.





06.1





06.2



06.3



06.4



06.5

